The switch does not include any connectors or wire terminals. It is recommended to use the stock connector body from the original stock handlebar switch and to source the correct terminals for proper fitment into the connector body. Refer to your factory wiring diagram to determine what wires perform what functions before disassembling the stock switch. Making some detailed notes here will be helpful later. Use of a multimeter will help you determine all of the functions of the stock switch. Once you have completed your notes, remove the stock connector from the stock switch. Install the proper terminals on the Motion Pro Switch, and insert the wires into the proper locations in the connector body according to your notes. Double check the security of the terminals in the connector before plugging it into the stock wiring harness. Check the function of both of the switches, making sure that the off position of the engine switch kills all power to the engine. **THIS IS A SIGNIFICANT SAFETY FEATURE. DO NOT RIDE THE MOTORCYCLE UNTIL YOU HAVE DETERMINED THAT THIS FEATURE IS FULLY FUNCTIONAL.**

