

Run Switch
Starter Button
Brake Switch
LED Switch
Rear Stop Switch
6 WAY BLOCK
Coils
Fusebox
MAIN
IG. Relay / RFID
Headlight
Tail Light
Spare
8 WAY BLOCK
RFID
6 WAY BLOCK
Ignition Relay
2 WAY BLOCK
Left
H Beam
Neutral
Oil
Right
Ground
Power
IG Power
Rectifier
5 WAY BLOCK
Silicone Rectifier
Reg
5 WAY BLOCK
2 WAY BLOCK
Oil Pressure Switch
Starter Motor
Neutral Switch
9 WAY BLOCK
Horn
Headlight Dimmer
Clutch Switch
Turn Signals
Start Sol.
Battery
Headlight Relay
Brake Light Relay
Turn Relay